

**Technical Specifications**

Standards	IEEE 802.3an (10GBase-T), 802.3ae(10GBase-SR, LR, ER or ZR)
Connectors	SFP+ slot, RJ45 TP port, DC power plug
RJ45 port	Full duplex, 10/100/1G/2.5G/5G/10G Base-Tx
SFP+ slot	Supports 10G speed SFPs
Power Adapter	Adapter with AC 100-240V input, 0.5A AC frequency: 50-60Hz, Output DC 5V/1A
Power Requirements	DC 5-12V, 5W max. power consumption
Dimensions	90mm x 60mm x 20mm (SFP not included)
Mounting	Wall or shelf (optional bracket needed)
Environmental Conditions	Operating Ambient Temperature: 0 to 50°C Operating Humidity: Maximum 85%, Non-condensing Storage Temperature: -30 to 70°C Storage Humidity: Maximum 95%, Non-condensing Indoor rated operating device
MTBF	65,000 hours

**Warning**

1. Use only indoors in climate-controlled environment.
2. Avoid looking directly into fibers or lasers while unit is powered.
3. Use only the AC adapter included with the unit (or with the LFC series chassis available separately)

**FCC and CE markings**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

This is a CE class B device, intended to be used in residential, commercial or industrial applications.

# Fiber Media Converters

10G Ethernet LFC series

**LFC-10GT-SFP**  
**LFC-10G-SS**



## User's Manual

## 10G Fiber Media Converters – LFC series

### Ordering Information

**LFC-10GT-SFP** 100/1G/2.5G/5G/10GBase-Tx Ethernet Media Converter to 10GBase-X SFP+ slot, AC adapter included

**LFC-10G-SS** multi rate high-speed Optical-Electrical-Optical repeater/transponder (155M to 11.7G rates), AC adapter included

### Overview

The LFC 10G series are high performance and reduced size 10G Ethernet fiber media converters. Physical dimensions have been reduced for minimum footprint and highest density attainable in 19" rack environment: 12 units/RU. Reliability is highly ranked with an MTBF exceeding 65,000 hours.

LFC 10G converters support multi-rate speed IEEE802.3an (10G Base-T) and 100/1G/2.5G/5G/10GBaseT to IEEE802.3ae (10G Base-X) protocols. The 10G-SS model is protocol transparent, supporting various data rates from 155M (Fast Ethernet) to 11.7G (SDH/SONET). Package includes AC adapter 100-240V to DC 5V and one User Manual.

### Features

- 100/1G/2.5G/5G/10GBase-T to 10GBase-X SFP+ slot conversion
- Data transparent (high range of data rates for 10G-SS: 155M to 11.7G)
- Forward Jumbo 9k+ packet size data
- Very low latency
- SFP+ slot supports any SFP transceiver type (SR, LR, ER, ZR and CWDM DWDM short and long-haul models)
- Supports SFP+ hot swap
- Installs in same LFC-CH12 high density chassis as the LFC-100 and LFC-1000 media converter series
- Low power consumption (less than 5W).

### DIP switch settings (only LFC-10G-SS model)

SW1	OFF OFF: 155M-11.3G	SW 3	OFF OFF: normal
SW2	ON OFF:: 10.35-11.7G	SW 4	ON OFF:: als active
Rate set	OFF ON: 8.5G	Converter behavior	OFF ON:lfp active
	ON ON:: NA		ON ON:: loop active

### DIP settings for LFC-10GT-SFP model

DIP SW	Function	Status	Description
1	LFP function	OFF	LFP Disabled
		ON	LFP Enabled
2	ALS function	OFF	ALS Disabled
		ON	ALS Enabled
3	Converter Type and Speed*	ON	Works either 10G or 1G fixed speed converter
4		ON	RJ45: 100/1G/2.5G/5G/10G and SFP: 10G speed

\*DIP SW 3 and 4 can only be ON position one at a time.



LFC-10GT-SFP



LFC-10G-SS

### LED Indicators

	Function
TP/LNK	Off – No link; On – RJ45 link OK; Blinking – data traffic present
SPD	Off – No link; On – 10G Base-T (on RJ45 port)
FX/LNK	Off – No link; On – Fiber link OK; Blinking – data traffic present
SFP1, SFP2	Off – No link; On – Fiber link OK; Blinking – data traffic present
LOOP	Off – No loop; On – Loop enabled
PWR	Off – No power available; On – Power is present

### Installation

1. Choose a flat secure surface with room for proper ventilation.
2. Power up the unit using the included AC adapter. Observe PWR LED status indicating proper power to the unit.
3. Connect RJ45 UTP port using Cat5e or better cable to another Ethernet device. Make sure the TP LED indicates proper connectivity.
4. Insert a Gigabit or Fast Ethernet rated SFP transceiver into the SFP slot. Make sure the fiber transceiver used matches the fiber type (MM or SM) and also a similar optical transceiver at the other end of the fiber. Inspect FX LED for proper fiber link status.

### Troubleshooting

1. No TP/LNK light: verify proper UTP cabling/pinout.
2. No FX/LNK light: verify fiber connectivity and fiber type. Consider cleaning up fiber connectors and SFPs with appropriate tools. Make sure Tx and RX ports are properly crossed between units. Make sure FX speed is properly set on DIP sw.
3. No PWR light: Use only the AC adapter included. Make sure AC power is available